



Gap occurs
between nut
and bearing
plate

Continuous Tiedown System